

Measuring the Surface Tackiness of Modified Asphalt Binders and Emulsion Residues using a Dynamic Shear Rheometer



PAVEMENT PRESERVATION & RECYCLING SUMMIT

PPRS PARIS 2015
FEBRUARY 22-25

Christine
Gorsuch
AkzoNobel





Coauthors

Stephanie Hogendoorn, AkzoNobel Surface Chemistry LLC

Codrin Daranga, Blacklidge Emulsions, Inc.

Joey McKay, Blacklidge Emulsions, Inc.

Presented at CTAA, St. John's, Canada 2013

Introduction



Tack Coat



Tracking from
Conventional Tack Coat

Source: Blacklidge Emulsions





Slippage


Source: NCHRP Report 712

Bond Strength of Trackless Product


Improved shear strength



0.14 l/m²



0.28 l/m²



0.70 l/m²

Source: NCHRP Project 9-40

Trackless Emulsions



- The residue is non-sticky
 - Use low penetration/ high softening point bitumen
 - Polymer modified systems
 - Other modifiers
- Typical US specifications:
 - <20 pen, softening point >85°C, residue
 - 50% minimum residue content
 - Applied undiluted
- Trackless products can also be hot-applied bitumen



Source: Blacklidge Emulsions

Laboratory test for tracking potential?

- Methods for adhesives, paint drying
- Some used on emulsion residue
- Can't distinguish similar samples
- Can't easily control temperature




Source: C. Creton, P. Fabre, "Tack" in: Adhesion Science and Engineering, Vol I, Elsevier (2002).

Dynamic Shear Rheometer

- Performance grading
- Pressure sensitive adhesives
- Compression and tension as well as oscillatory, rotational
- Accurate control of temperature




Sample of Bitumen





DSR Results in Compression-Tension Mode



Method Development

› To get results on previous slide we looked at method parameters: contact time, applied force, speed in tension

- **Goal: Simulate worst case of vehicle stopped on road**
- **Chose method parameters to give resolution between samples; can be can be changed to refine as needed**
- **Sample thickness was important**
- **Both TA Instruments and Anton Paar DSRs**




Source: NCHRP Report 712







Method Development: Effect of Speed in Tension




Effect of Temperature: 25°C, *both non-tacky*



Effect of Temperature: 45°C, *both tacky and tracking*





Effect of Temperature: 35°C, *differences resolved*






Development of a Test Specification

Correlation of Log(Force-Time Area/Thickness) versus Temperature






Development of a Test Specification Tack Parameter for Various Samples



PPRS Paris 2015 - Measuring the Surface Tackiness of Asphalt Binders and Emulsion Residues using a DSR


Field Relevant Results: DSR of Modified Bitumens



PPRS Paris 2015 - Measuring the Surface Tackiness of Asphalt Binders and Emulsion Residues using a DSR




Emulsion Residues: Unmodified and Modified, 25°C




Emulsion Residues:

Recovered by Oven and Low Temperature Evaporation (LTE)



Example with Modifiers



Conclusion

- Objective
- Can distinguish similar samples
- Works for different DSR makes
- Proposed spec reliably predicts tracking
- Progress in predicting field performance
- Consistent sample preparation important
- Can evaluate different mechanisms for TT

